



Installing Razer Mac DeathAdder driver v.1.0.1.

Once the setup.exe file is executed, you will be prompted with the following screen.




Click on Continue to proceed to the next step of Installation.




In this screen, you will be informed that the Razer Mac DeathAdder application can be found in the Applications folder - /Applications/RazerDeathAdder.app

The uninstaller and the support files for the Razer Mac DeathAdder mouse can be found in the Utilities folder - /Applications/Utilities/RazerDeathAdderUninstaller.command.

Click on Continue to proceed.




You will be presented with the Software License Agreement. Please read thoroughly and then click on Continue.



To continue, click on Agree.




You are then prompted to select the preferred volume to install the Razer Mac DeathAdder driver. Once selected, click on Continue.




You can still change your preferred installation location before installing. Do so by clicking on Change Install Location.


If you do not prefer to change the location, simply click install.



You will be prompted to enter in the administrator password. Click OK once done.



You will be prompted that a restart is required to complete the installation. Click Continue Installation to proceed.



Upon successful installation, you will be prompted with the following screen.