



STREAMER COMPANION APP

MASTER GUIDE

CONTENTS


1. WHAT'S NEEDED..... 2

2. THE STREAMER COMPANION APP 3

3. LEGALESE..... 16

1. WHAT'S NEEDED

- Windows® 7 64-bit (or higher)
- Razer Synapse with Chroma Connect module
- Razer ID log in
- Internet connection for software installation

 *As the Streamer Companion App will be using the lighting effects from Razer Synapse, make sure to download and install the Chroma Connect module from Razer Synapse.*


2. THE STREAMER COMPANION APP

i *Disclaimer: The features listed here require you to log in using your Razer ID. Internet connection is required for installation, updates and cloud-based features. All listed features are subject to change based on the current software version, connected device(s), and supported apps and software.*

The Streamer Companion App allows you to take your showmanship to new heights with stream reactive emoticons that synchronize with your audiences emotes, alerts and shout outs. Customize various lighting alerts on your Razer Chroma-enabled devices – from receiving donations, follows, chat messages, subscriptions, and a whole lot more.


LINKING ACCOUNTS


On the Streamer Companion App's first launch, the Dashboard tab will require you to link any of your streaming platforms to the app first. This will allow the app to control how your device(s) will react to any activity made on your streams.



DASHBOARD


The Dashboard tab provides an overview of all activities made on your stream such as new subscriptions, donations, chat messages, and more. You may also use this tab to test how your device(s) will display an alert for each event. [Learn more about Alerts](#)

 Alerts will only be shown on your device(s) if you have enabled and configured each event from the Alerts tab.




ALERTS

The Alerts tab enables you to toggle each event and set which and how your device(s) will react to any activities made on your stream. By default, all events are disabled.



Setting Up Event(s)

Each event represents a streaming activity and can be configured to display alerts on selected device(s) using your preferred settings such as user and/or gifted subscription alerts, or even the setting the amount of Bits per Cheer required to trigger an alert.




Listed below are the events which can be configured to show alerts on your device(s):

Name	Description	How to set up
Chat messages	Show an alert when you receive a chat message with the preferred amount of chat lines or chat message content	Add and enable a Chat event and set if it will either be triggered by your preferred amount of chat lines amount or message content
Cheer	Display an alert when a user Cheers with the preferred amount of Bits	<ul style="list-style-type: none">▪ Enable Minimum Cheer (1) and set your preferred amount of Bit(s) to trigger this event▪ Enable any of the set cheer amounts (200, 500, 1000, 5000) to trigger this event when you receive the corresponding amount of Bits
Follows	An alert will be shown when someone follows your channel	No further setup required
Subscriptions	Display an alert when a user subscribes or gifts you with subscribers	<ul style="list-style-type: none">▪ Under General, enable Subscriptions Alerts to trigger this event when someone subscribes▪ Under Gifted, enable Gifted Alerts to trigger this event when someone gifts a subscription
Hosts	Show an alert when a host broadcasts your channel with the preferred number of viewers	Set the required number of viewers to trigger this event
Raids	Display an alert when a user Raids your channel with the preferred number of raiders	Set the required number of raiders to trigger this event
Donations	Show an alert when you receive your preferred amount of donation	Select your region's currency and set the required amount of donation to trigger this event

Whisper	An alert will be shown when you receive a whisper with the preferred amount of chat lines or chat message content	Add and enable a Whisper event and set if it will alert you when a chat line is reached or contains your preferred message
Background	Set a default effect on your device(s) when there are no events present	No further setup required


Adding Device(s)

On the event that you want to customize, click on **Add Device** to assign Razer streaming specific and/or Razer Chroma-enabled device(s) which will display an alert when the event is triggered.




i *Selecting multiple Razer Chroma-enabled devices will consume more CPU resources.*

Some devices may feature their own settings button (⚙️) as a quick access to some settings such as changing device orientation or even changing which devices are included in the Chroma Devices. Any added device, however, can be removed from any event by clicking its corresponding **Remove** link.



Customizing lighting effects

With your preferred device(s) added to an event, you may now set a lighting effect that will be displayed on each added device when the event is triggered and set how long an effect will be shown on each device.



Listed below are the lighting effects that can be selected and applied as an alert:

Name	Description	How to set up
Breathing	The LEDs will fade in and out of the selected color(s)	Select up to 2 colors or randomize colors
Emote	An emote will be shown on the LEDs of compatible device(s)	Select an emote from the emote presets
Fire	The LEDs will light up in warm colors to mimic the motion of flames	No further customization required
Spectrum cycling	The lighting will cycle between 16.8 million colors	No further customization required


Starlight	Each LED will have a chance of fading in and out at a random time and duration	Select up to 2 colors or randomize colors and select a duration
Wave	The lighting will scroll in the direction selected	Select either left-to-right or right-to-left wave direction
Wheel	The lighting will rotate in the direction selected	Select either counterclockwise or clockwise wheel direction

 *Available lighting effects may vary for each device.*

To set how long a selected effect will be shown on your device, set your preferred duration (in seconds) in the **End after** field. You may also use the **Test** button to see how the alert will be shown on your device(s) when the event is triggered.

EDITOR


Use the Editor tab to create your own effect for any of your Razer Streaming Specific devices or import a static or animated lighting effect* as an alert for any streaming event.



**Available only for selected devices.*


Creating Custom Alerts

On the Custom Alerts section, clicking on any device's add button (+) allows you to add a custom alert on the corresponding device. You can rename, duplicate, or delete a custom alert by clicking on the miscellaneous button (...).




Customizing an LED's color

To change any LEDs' color, you must first select which LEDs will be customized. To select LED(s), you may click on an LED, select multiple LEDs individually using ctrl + click, or click and drag to select multiple LEDs.



Once you have selected LEDs, you may now use the Properties located on the right side of the Editor tab.



- A. **Color field.** Click on any preferred color to change the color of the selected LED(s).
- B. **Active color.** Shows which color has been selected.
- C. **Shade slider.** Adjust the shade of the selected color.
- D. **Color values.** Enter the Hex value or the RGB values of the color that you want to use.
- E. **Color swatches.** Click on the add button (+) to add the Active color as a preset.

Importing 8 x 8 GIFs (Available only for selected devices)


Use your preferred static or animated GIFs on compatible device(s) by importing an 8 x 8 GIF file as an effect.

Preview on Device

Show how the custom effect will be displayed on a connected device.


Using Custom Alerts

To use any custom alert, simply select it on the Effects list of the corresponding device from the Alerts subtab.




CONNECTIONS

The Connections tab allows you to link or unlink all available streaming platforms supported by the Streamer Companion App.



SETTINGS & OTHER FEATURES

The Settings window, accessible by clicking the (⚙) button, enables you to configure the startup behavior and display language of the Streamer Companion App, change the orientation of supported Razer streaming devices, or view the master guides of all connected Razer devices.



General

The default tab of the Settings window. The General tab enables you to change the software's display language and start-up behavior.

Device Orientation

Identify how any supported Razer streaming device was set up to control the orientation of alerts on the corresponding device.

About tab

Displays brief software information, copyright statement and provides relevant links for its terms of use. You may also use this tab to check for software updates, or as a quick access to Razer's social communities.

Updates

The Streamer Companion App provides an accessible Upgrade button (↕) located just beside your avatar and automatically displayed whenever an upgrade is available.

3. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2019 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Powered by Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

TWITCH and the TWITCH Logo are trademarks of Twitch Interactive, Inc. or its affiliates.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Streamer Companion App (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.