
DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

- RZ09-03100

DRIVER NAME AND VERSION

Intel Software Guard Extensions (SGX) 2.3.100.49777

INSTRUCTIONS

Note: This download is for the original driver that was installed on your Razer Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.

1. Ensure that your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
2. Save any open documents on your computer and close all other programs before attempting this update.
3. Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to the location of your choice (such as your desktop).

Driver: <http://rZR.to/1h62v>


4. Once you have extracted the file proceed to the installation steps below.

INSTALLATION PROCESS

1. Right click on the "InstallPackage.bat" file and select "Run as administrator" from the menu to initiate the installation process.

| Name | Date modified | Type | Size |
|--|----------------------|--------------------|--------|
| PSW_INF_19H1 | 26/09/2019 7:37 A... | File folder | |
| InstallPackage | 26/09/2019 7:37 A... | Windows Batch File | 1 KB |
| Intel SGX Installation Guide for Windows ... | 26/09/2019 7:37 A... | Adobe Acrobat D... | 282 KB |
| Intel SGX PSW Release Notes for Windo... | 26/09/2019 7:37 A... | Adobe Acrobat D... | 392 KB |

2. A CMD window will pop up. Wait for the installation process to complete.



```
C:\Windows\system32\cmd.exe

####Right click the InstallPackage.bat and choose run as administrator####

C:\Users\apssg\Desktop\Lynette2UMA\intel_sgx_2.3.100.49777\intel_sgx_2.3.100.49777>pnputil /add-driver "C:\Users\apssg\Desktop\Lynette2UMA\intel_sgx_2.3.100.49777\intel_sgx_2.3.100.49777\PSW_INF_19H1\sgx_base.inf" /install
Microsoft PnP Utility

Adding driver package: sgx_base.inf
Driver package added successfully.
Published Name: oem17.inf
Driver package is up-to-date on all applicable targets.

Total driver packages: 1
Added driver packages: 0

C:\Users\apssg\Desktop\Lynette2UMA\intel_sgx_2.3.100.49777\intel_sgx_2.3.100.49777>pnputil /add-driver "C:\Users\apssg\Desktop\Lynette2UMA\intel_sgx_2.3.100.49777\intel_sgx_2.3.100.49777\PSW_INF_19H1\sgx_psw.inf" /install
Microsoft PnP Utility

Adding driver package: sgx_psw.inf
Driver package added successfully.
Published Name: oem18.inf
Driver package is up-to-date on all applicable targets.

Total driver packages: 1
Added driver packages: 0

C:\Users\apssg\Desktop\Lynette2UMA\intel_sgx_2.3.100.49777\intel_sgx_2.3.100.49777>PAUSE
Press any key to continue . . .
```

3. Press any key to close the window.