DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

• RZ09-03100

DRIVER NAME AND VERSION

Intel Wireless AX (WiFi) Driver Version 21.30.2.1

INSTRUCTIONS

Note: This download is for the original driver that was installed on your Razer Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.


- 1. Ensure that your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- 2. Save any open documents on your computer and close all other programs before attempting this update.
- 3. Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to a location of your choice (such as your desktop) to locate the files for the installation process.

http://rzr.to/TEeTF

4. Once you have extracted the file proceed to the installation steps below.

INSTALLATION PROCESS

1. To initiate the initial process, click on the "Autorun.exe" (Application) as shown in the image below:



2. Upon clicking the Autorun.exe (Application), you will be met by the Intel® PROSet/Wireless Software. You will be given the choice to Repair, Modify, or Uninstall the software from your system.



3. After making your selection, you will be met with a progress bar. once the progress bar is complete, you will be prompted to finish the installation and restart your

system. Note that it is required to restart to finalize all components and complete the install.

