## razer blade 14 (2013) windows 8.1 upsrade Instructions

Please follow the steps below to upgrade your Razer Blade from Windows 8.0 to Windows 8.1.

Step 1: Enter Bios mode by tapping at F1 or Del upon booting up system. In "Security" tab, ensure "Secure Boot" is enabled. Otherwise, select the option "Install All Factory Default Keys". "Save and Exit" Bios menu by pressing F4. Shutdown system completely.

Step 2: Perform Windows update and make sure to install KB2871389 – to enable system 'see' Windows 8.1 update link

Step 3: Before starting the upgrade please download Windows 8.1 Killer Suite Driver for Razer Blade at <a href="https://www.razersupport.com/downloads">www.razersupport.com/downloads</a>.

Step 4: Please un-install the following applications and drivers and restart your Razer Blade when prompted to do so.

All NVIDIA applications \ Drivers
All Killer Suite\Drivers
Dolby Pro Surround Drivers
Realtek HD Audio Drivers
Intel HD graphic Drivers
Razer Comms

Step 5: Install the Killer Suite driver for Windows 8.1.


Step 6: Go to Store application and find the update for Windows 8.1. If Windows 8.1 update not shown in the store apps, please download Windows 8.1 Upgrade Assistant from Microsoft website - <a href="http://windows.microsoft.com/en-sg/windows-8/upgrade-assistant-download-online-faq">http://windows.microsoft.com/en-sg/windows-8/upgrade-assistant-download-online-faq</a>

## Store


**Update Windows** 



Step 7: Click the link and select download to start upgrading your OS to Windows 8.1.



Step 8: Microsoft Store will start downloading the OS, the speed of the upgrade will depend on your network connection.



Step 9: At this point Windows 8.1 is upgrading your Razer Blade & will restart several times during this process. This can take up to an hour for the upgrade to complete.

Electron Back to Windows. Please go through the OS registration process again.

License terms

Please read this to you know what you're agreeng to.

MICROSOTS SOFTWARE LICENSE AGREEMENT WITH COMPUTER MANUFACTURE OR SOFTWARE INSTALLER, OR MICROSOTS

WINDOWS & 1

This you compare presentable with or updating to Microsoft Vindows 8.1 This is a license agreement between you and the compater membelaturers or whome installer or additionate with windows 5 too. this is an agreement between you and followed the Windows 1 to with your compater decircles by and followed to window 1 to with your compater decircles by and followed to windows 1 to with your compater decircles by and followed to window 1 to windows 5 too. the bit is an agreement between you and Microsoft Corporation for based on water you live, one of the affiliation; instead. This agreement between you and Microsoft Corporation for based on water you live, one of the affiliation; instead. This is affirmed the Additional Terms and Limited Vinterrainty follow and cortain greater detail. You should review the entire agreement between you have come in a self-window 5 too. The self-window 6 too. The self-w

Step 11: Once you boot into the desktop, uninstall NVidia Video driver that comes with Windows 8.1. Go to Device Manager → Display Adapters → NVidia GeForce GTX 765M, right click and select uninstall. Check "Delete the driver software for this device" then restart the system.

Step 12: Please download and install updated Windows 8.1 Drivers\* and Razer Synapse. You can find the drivers at www.razersupport.com/downloads.

## \*Important Note:

o Win 8.1 Drivers

Please install Windows drivers according to following sequence:

- → Realtek High Definition Audio
- → Dolby Digital Plus HT
- → Nvidia GeForce GTX 765M
- → Killer Suite (Please uninstall and reinstall the Killer Suite driver again)
- o Synapse
- o Razer Comms

Now start Enjoying Windows 8.1.