

# DRIVER INSTALLATION INSTRUCTIONS

RAZER BLADE 15" (2018) BASE MODEL INTEL WIRELESS AC (WLAN)
DRIVER VERSION 20.60.0.7

### DRIVER INSTALLATION INSTRUCTIONS

#### APPLICABLE MODEL NUMBERS

• RZ09-02705

#### **DRIVER NAME AND VERSION**

Intel Wireless AC (WLAN) Driver Version 20.60.0.7

#### **INSTRUCTIONS**

**Note:** This download is for the <u>original driver</u> that was installed on your Razer Blade Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.


- Ensure your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- Please save any open documents on your computer and close all other programs before attempting this update
- Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to a location of your choosing (such as your desktop) to locate the files for the installation process.

#### http://rzr.to/BSMwp

• Once you have extracted the file proceed to the installation steps below.

## **INSTALLATION PROCESS**

1. To initiate the installation process, click on the Autorun.exe (Application) as shown in the image below:



2. Upon clicking the Autorun.exe (Application), you will be met with the Intel® PROSet/Wireless Software. You will be given the choice to Repair, Modify, or Uninstall the software from your system.



3. After making your selection, you will be met with a progress bar. Once the progress bar is complete, you will be prompted to finish the installation and restart your system. Note that it is required to restart to finalize all components and complete the install.



4. End.