

DRIVER INSTALLATION INSTRUCTIONS

RAZER BLADE 15" (2018) BASE MODEL REALTEK AUDIO ALC298 APP VERSION 1.2.147.0

DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

RZ09-02705

DRIVER NAME AND VERSION

Realtek Audio ALC298 App Version 1.2.147.0

INSTRUCTIONS

Note: This download is for the <u>original driver</u> that was installed on your Razer Blade Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.

- Ensure your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- Please save any open documents on your computer and close all other programs before attempting this update
- Download the driver from the link below. You will need to right-click the .zip folder and choose to extract the files to a location of your choosing (such as your desktop) to locate the files for the installation process.


http://rzr.to/vnzWa

• Once you have extracted the file proceed to the installation steps below.


INSTALLATION PROCESS


Note: This application is dependent upon the installation of the Realtek Audio ALC298 Driver. Please install the driver first if you have not already done so.

 To initiate the installation process, click on the O2f0c026d12848b29004eded3adf3df7.appxbundle (APPXBUNDLE File) as shown in the image below.



2. Upon clicking on the 02f0c026d12848b29004eded3adf3df7.appxbundle (APPXBUNDLE File), you will be prompted to install the Realtek Audio Control application. Once installed, the application will launch (this is dependent upon whether the checkbox 'Launch When Ready' is checked off).





3. End