



DRIVER INSTALLATION INSTRUCTIONS

RAZER BLADE 15" (2019) ADVANCED MODEL - INTEL CHIPSET DRIVER

DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

- RZ09-02886
- RZ09-02887
- RZ09-02888

DRIVER NAME AND VERSION

Intel Chipset Driver version 10.1.16.6

INSTRUCTIONS

Note: This download is only intended for the Razer Blade Laptop(s) listed above. Updates for this driver may be available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.


- Ensure your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- Please save any open documents on your computer and close all other programs before attempting this update.
- Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to a location of your choosing (such as your desktop) to locate the files for the installation process.

<http://rzt.to/gwtDW>


- Once you have extracted the file proceed to the installation steps below.

INSTALLATION PROCESS

1. Open the SetupChipset.exe (Application)
2. Click through the prompts as follows: Next > Accept > Install



3. Click 'Yes' when prompted by the User Account Control to confirm the application is okay to make changes.
4. A progress bar will appear indicating a rough estimate of the remaining time required until installation is complete. You may see your screen flicker or lose function of your keyboard and or touchpad momentarily.
5. Upon completing the installation, you will be given the option to 'Restart Now' or 'Restart Later'. A complete reboot of your system is required to finish the update process successfully.



6. End