



DRIVER INSTALLATION INSTRUCTIONS

RAZER BLADE 15" (2019) ADVANCED – INTEL MANAGEMENT ENGINE
DRIVER

DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

- RZ09-02886
- RZ09-02887
- RZ09-02888

DRIVER NAME AND VERSION

Intel Management Engine Driver Version 1851.12.0.1193

INSTRUCTIONS

Note: This download is only intended for the Razer Blade Laptop(s) listed above. Update for this driver may be available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.


- Ensure your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- Please save any open documents on your computer and close all other programs before attempting this update.
- Download the driver from the link below. You will need to right-click the zipped folder and choose to extract the files to the location of your choice (such as your desktop) to locate the files for the installation process.

<http://rZR.to/cmcRe>


- Once you have extracted the file proceed to the installation steps below.

INSTALLATION PROCESS

1. To begin the install process, click on the SetupMe.exe (application).




2. When prompted by the User Account Control dialogue box, click 'Yes' to confirm changes to be made to your system by the Intel driver.
3. You will be prompted through the following options: Next > Click the 'I accept' checkbox followed by 'Next'



4. A progress bar will appear indicating the approximate time remaining until the installation is complete. Please note that your screen may flicker during the installation.

5. Once complete, click 'Finish', as shown in the image below.



6. End