

---

## DRIVER INSTALLATION INSTRUCTIONS

### APPLICABLE MODEL NUMBERS

- RZ09-03148

### DRIVER NAME AND VERSION

Intel® UHD Graphics 630 Driver Version 26.20.100.6911 -4ID

### INSTRUCTIONS

**Note:** This download is for the original driver that was installed on your Razer Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.

- Ensure that your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- Save any open documents on your computer and close all other programs before attempting this update.
- Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to location of your choosing (such as your desktop) to locate the files for the installation process.


<http://rZR.to/chWoj>

- Once you have extracted the file proceed to the installation steps below.

---

## INSTALLATION PROCESS

- To initiate the initial process, click on the igxpin.exe (Application) as shown in the image below:



<input type="checkbox"/>	Name	Date modified	Type	Size
	Graphics	6/8/2019 6:59 PM	File folder	
	Lang	3/7/2019 4:56 PM	File folder	
	x64	3/7/2019 4:56 PM	File folder	
	autorun.inf	5/6/2019 4:28 PM	Setup Information	1 KB
	DIFxAPI.dll	5/6/2019 4:28 PM	Application extens...	312 KB
<input checked="" type="checkbox"/>	igxpin.exe	5/6/2019 4:29 PM	Application	1,001 KB
	Installation_Readme.txt	5/6/2019 4:29 PM	Text Document	52 KB
	mup.xml	5/6/2019 4:29 PM	XML Document	13 KB
	readme.txt	5/6/2019 4:29 PM	Text Document	4 KB
<input type="checkbox"/>	Setup.if2	5/6/2019 4:29 PM	IF2 File	38 KB

- The User Account Control window may pop up to confirm changes that will be made by the application. Click "Yes" to allow the application to launch.
- The Intel® Chipset Device Software will prompt you to exit all other programs. Once done with the message, click "Next" to begin and follow the on-screen prompts as necessary as shown in the image below:

