DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

• RZ09-03148

DRIVER NAME AND VERSION

NVIDIA Graphics Driver Version 26.21.14.3170

INSTRUCTIONS

Note: This download is for the original driver that was installed on your Razer Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.


- 1. Ensure that your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- 2. Save any open documents on your computer and close all other programs before attempting this update.
- 3. Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to location of your choosing (such as your desktop) to locate the files for the installation process.

http://rzr.to/SHwaw


4. Once you have extracted the file proceed to the installation steps below.

INSTALLATION PROCESS

1. To initiate the initial process, click on the setup.exe (Application) as shown in the image below:



- 2. User Account Control will appear on the screen. Click "Yes" to continue.
- 3. The NVIDIA Graphics Driver will check you system if meets the requirements.



4. Once the driver recognizes the compatibility of the system, it will proceed with the License Agreement. Click "AGREE AND CONTINUE".



5. Select your preferred install option. "Express" is the recommended option. Click "Next" after selecting.



6. Install progress will appear on the screen and will notify once finished. Click "Close" to complete.



7. The installation is finished.