UPDATER INFORMATION

APPLICABLE MODEL NUMBERS

RZ09-03100

DRIVER NAME AND VERSION

Intel Chipset Driver Version 10.1.12.2

INSTRUCTIONS

Note: This download is for the original driver that was installed on your Razer Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade, please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.

- 1. Ensure that your Blade is plugged into a wall outlet and not just running on battery before proceeding.
- 2. Save any open documents on your computer and close all other programs before attempting the update.
- 3. Download the firmware from the link below. You will need to right click the .zip folder and choose to extract the files to a location of your choice (such as your Desktop).

http://rzr.to/bOinC


4. Once you have extracted the file, proceed to the installation steps below.

INSTALLATION PROCESS

1. To initiate the initial process, double-click on the "SetupChipset.exe" (Application) as shown in the image below:



- 2. The User Account Control window will pop up to confirm changes that will be made bt the application. Click "Yes" to allow the application to launch.
- 3. The Intel Chipset Device Software will prompt you to exit all other programs. Once done with the message, click "Next" to begin and follow the on-screen prompts as necessary as shown in the image below:



- 4. A license agreement will appear on the screen. Read the terms of the agreement and once donw, click "Accept".
- 5. A confirmation of the installation will appear, click "Install".