
DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

- RZ09-03135

DRIVER NAME AND VERSION

Realtek Card Reader Driver Version 10.0.18362.21321

INSTRUCTIONS

Note: This download is for the original driver that was installed on your Razer Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.


1. Ensure that your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
2. Save any open documents on your computer and close all other programs before attempting this update.
3. Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to location of your choosing (such as your desktop) to locate the files for the installation process.

<http://rZR.to/ko4VS>

4. Once you have extracted the file proceed to the installation steps below.


INSTALLATION PROCESS

1. To initiate the initial process, click on the "setup.exe" as shown in the image below:



data2	Cabinet File	1 KB
ISSetup.dll	Application extension	692 KB
layout.bin	BIN File	1 KB
pkgconf	Configuration settings	3 KB
readme	Text Document	2 KB
setup	Application	512 KB
setup	Configuration settings	2 KB
setup.inx	INX File	183 KB

2. User Account Control will appear on the screen, click "Yes" to continue.
3. A progress bar will appear. Wait for the installation to finish.



4. After the installation is complete. Click Finish to exit the installation wizard.

