

FIRMWARE INSTALLATION INSTRUCTIONS

RAZER RIPSAW HD FIRMWARE UPDATER GUIDE

DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

• RZ20-02850

DRIVER NAME AND VERSION

Razer Ripsaw HD Firmware Updater v1200.13

• http://rzr.to/XRlwm

INSTALLATION PROCESS

- 1. Download the latest firmware update by downloading the link found above.
- 2. Close Razer Synapse and all other running applications before proceeding with the update.
- 3. Run the downloaded firmware (The installer will prompt you to close Synapse and all other applications, if you have already done so, left click "OK" to proceed).
- 4. Connect the Razer Ripsaw HD and click "Update".
- 5. Wait for the update to complete.
- 6. Once the firmware has been successfully applied, left-click "Close" to exit the installer.