



FIRMWARE INSTALLATION INSTRUCTIONS

RAZER BASILISK ULTIMATE FIRMWARE UPDATER GUIDE

UPDATER INFORMATION

APPLICABLE MODEL NUMBERS

1. RZ01-03170

DRIVER NAME AND VERSION

BasiliskUltimate_Mouse_FirmwareUpdater_v1.06.00_r1

Download Link : <https://rZR.to/ZZ4qJ>

RELEASE NOTES:


- Automatically detect old and new hardware lighting strip and apply their respective lighting parameters
- Added a 28ms wait period after first click to avoid accidental clicks
- Fixed an issue where the mouse cursor jumps or skips when used with certain mouse mats
- Improve sleep to wake response time
- Fixed an issue where there is no low power indication when lighting brightness is set to zero
- Improved USB dongle detection

PREPARATIONS

1. Make sure your laptop is plugged into a wall outlet and not just running on battery before proceeding.
2. Save any open documents on your computer and close all other programs before attempting the update.
3. Download the firmware from the link above.
Note: It is recommended to download and install the latest firmware version.
4. Run the updater and follow the installation steps below:

INSTALLATION PROCESS


1. Run the updater as shown below:




2. You may be prompted to confirm changes on your device by the User Account Control. Click "Yes" to confirm these changes.




3. Click "NEXT" to proceed. The installer will close all running Razer applications if you have not done so yet.




4. Connect the USB wireless dongle to the computer and click "UPDATE".




5. Wait until the update process is complete. Do not interrupt.




6. The firmware update has been successful. Click "NEXT".




7. Connect the device to your PC with the supplied cable and then click "UPDATE".



8. Wait until the update process is complete.



9. When the update is complete, click "NEXT".



10. Finally, click "CLOSE".

