



# FIRMWARE INSTALLATION INSTRUCTIONS

RAZER USB SOUND CARD FIRMWARE UPDATER GUIDE



---

## UPDATER INFORMATION

### APPLICABLE MODEL NUMBERS

- RZ04-03230

### DRIVER NAME AND VERSION

Razer USB Sound Card\_FirmwareUpdater\_v0011\_r1

Download the firmware updater here: <https://rZR.to/FChiz>

### RELEASE NOTES:

- Fixed an issue where audio is heard software on one earcup after continuously adjusting the volume
- Fixed an issue where there is a popping sound when connected to PC


---

## INSTALLATION PROCESS


1. Download the latest firmware update by downloading the link found above.
2. Close Razer Synapse and all other running applications before proceeding with the update.



3. Run the downloaded firmware (The installer will prompt you to close Synapse and all other applications, if you have already done so, left click "OK" to proceed) then click "NEXT" to proceed




4. Plug in the headset to your PC or laptop. If an update is required, click "UPDATE".






5. Wait for the update to finish.



6. Remove and then reinsert the headset to your PC or laptop.





7. A confirmation message will come up when the update is complete. Click "CLOSE".

