DRIVER INSTALLATION INSTRUCTIONS

APPLICABLE MODEL NUMBERS

RZ09-03009

DRIVER NAME AND VERSION

Intel Bluetooth Driver Version 20.120.0.3

INSTRUCTIONS

Note: This download is for the original driver that was installed on your Razer Laptop. Updates for this driver are available via standard Windows Updates. To ensure you have the latest driver installed on your Blade please make sure to apply all available updates from Windows.

Please follow the instructions below to download and install the original driver for your Blade. Following the installation, it is recommended to search for any available Windows Updates.

- 1. Ensure that your Blade is plugged into a wall outlet and not running on battery alone before proceeding.
- 2. Save any open documents on your computer and close all other programs before attempting this update.
- 3. Download the driver from the link below. You will need to right click the .zip folder and choose to extract the files to the location of your choice (such as your desktop).


http://rzr.to/Q2JxL

4. Once you have extracted the file proceed to the installation steps below.

INSTALLATION PROCESS


For New Install

1. Double-click on the "Autorun.exe" file to initiate the installation process.




2. The User Account Control window may pop up to confirm changes that will be made by the application. Click "Yes" to allow the application to launch.


3. On the welcome screen, click "Next" to proceed with the installation.




4. Tick "I accept the terms in the License Agreement" and click "Next".




5. Select "Typical", then click "Next".




6. Click "Install" to begin the installation process.



7. Wait for the installation process to complete. Then, click the "Next" button to continue.




8. Click "Finish" once the installation process is complete.



For Repair


1. Double-click on the "Autorun.exe" file and to initiate the installation process.




2. On the welcome screen, click "Next" to proceed with the repair.



3. Select "Repair", then click "Next".



4. Click "Repair" to begin the repair process.



5. Click "Finish" once the repair process is complete.

