



RAZER TOMAHAWK MINI-ITX

MASTER GUIDE

To build the ultimate gaming desktop, it begins with a frame that can support the performance within. Meet the **Razer Tomahawk Mini-ITX**—a Mini-ITX metal gaming chassis that exudes both form and function, equipped with premium features to accommodate your idea of the perfect rig, whatever it may be.

CONTENTS

1. WHAT’S INSIDE 3

2. LET’S GET YOU COVERED 5

3. TECHNICAL SPECIFICATIONS..... 6

4. INSTALLING RAZER SYNAPSE 3 7

5. CONFIGURING YOUR TOMAHAWK MINI-ITX 8


6. SAFETY AND MAINTENANCE 14

7. LEGALESE..... 15

1. WHAT'S INSIDE

- Razer Tomahawk Mini-ITX Gaming Chassis

Model No. RZ21-0140



- A. USB Type C port (up to 3.2 Gen 2)
- B. 3.5mm audio jack
- C. 3.5mm mic jack
- D. Power Button
- E. Reset Button
- F. USB Type A ports (up to 3.2 Gen 1)

- G. Detachable top panel
- H. Detachable swivel glass doors
- I. Detachable front panel
- J. Underglow lighting Powered by Razer Chroma RGB

▪ Accessories Pack*




- A. Screws for motherboard x6
- B. Anti-vibration rings for 2.5" SSD / HDD mount x12
- C. Screws for PSU mount x4
- D. Screws for 2.5" SSD mount x12
- E. Thumb screw for 2.5" HDD mount x1
- F. Screws for fan mount x24
- G. Hook and loop straps x6

**Extra items included for spare parts*

2. LET'S GET YOU COVERED

You've got a great product in your hands, complete with a 1-year limited manufacturer's warranty*. Now maximize its potential and score exclusive Razer benefits by registering at razerid.razer.com

*Your product's serial number
can be found here.*



**Warranty may vary by region and is subject to applicable local law.*


Got a question? Ask the Razer Support Team at support.razer.com

3. TECHNICAL SPECIFICATIONS

Chassis Type	Mini-ITX Chassis
M/B Supported	Mini-ITX
PSU Support	SFX / SFX-L
Graphics	Supports Graphics up to 320mm
Size	356mm x 202mm x 321.5mm (L x W x H)
Weight	6.8Kg
Chassis Type	Mini-ITX Chassis
M/B Supported	Mini-ITX
PSU Support	SFX / SFX-L
Graphics	Supports Graphics up to 320mm
Size	356mm x 202mm x 321.5mm (L x W x H)
Weight	6.8Kg

4. INSTALLING RAZER SYNAPSE 3

Razer Synapse 3 allows your chassis and other supported Razer peripherals to download drivers and firmware updates. Razer Synapse 3 also enables your custom settings to be stored on cloud servers so that they can be accessed anytime, anywhere. To start using Razer Synapse 3, follow these steps:



1. Make sure your computer has an active internet connection.
2. Install Razer Synapse when prompted* or download the installer from razer.com/synapse.
3. Sign up for a Razer ID or log in with an existing account**.
4. Wait until Razer Synapse 3 automatically downloads and installs the necessary drivers.

**Applicable for Windows 8 or later*

***You may also continue as a guest; however, you won't be able to store any of your settings to the cloud.*

5. CONFIGURING YOUR TOMAHAWK MINI-ITX


i *Disclaimer: The features listed here require you to log into Razer Synapse 3. These features are also subject to change based on the current software version and your Operating System.*

SYNAPSE TAB

The Synapse tab is your default tab when you first launch Razer Synapse.

Dashboard

The Dashboard subtab is an overview of Razer Synapse where you can access all your Razer devices, modules, and online services.




SYSTEM

The System tab is the main tab for your gaming chassis. This tab allows you to customize its brightness, lighting effects, and power saving feature. Changes made under this tab are automatically saved to your system and cloud storage.

Lighting

The Lighting subtab enables you to modify your Razer device's light settings.



Brightness








You can turn off the lighting on the gaming chassis by toggling the Brightness option or increase/decrease the luminance using the slider.


Switch Off Lighting

This is a power saving tool which allows you to disable the lighting on the gaming chassis in response to your display turning off.


Effects

A number of effects can be selected and applied to your gaming chassis' lighting, as listed here:

	Name	Description	How to set up
	Audio meter	The LEDs will light up according to the audio level with a default spectrum of colors	Select a Color Boost level
	Breathing	The lighting fades in and out of the selected color(s)	Select up to 2 colors or randomize colors
	Fire	The LEDs will light up in warm colors to mimic the motion of flames	No further customization required
	Spectrum cycling	The lighting will cycle between 16.8 million colors indefinitely	No further customization required
	Starlight	Each LED will have a chance of fading in and out at a random time and duration	Select up to 2 colors or randomize colors and select a duration
	Static	The LEDs will remain lit in the selected color	Select a color
	Wave	The lighting will scroll in the direction selected	Select either left-to-right or right-to-left wave direction

If you have other supported Razer Chroma-enabled devices, you can synchronize their quick effects with your Razer device by clicking the Chroma Sync button ().

Advanced Effects


The Advanced Effects option allows you to choose a Chroma Effect you want to use on your Razer Chroma-enabled peripheral. To start making your own Chroma Effect, simply press the Chroma Studio button (). [Click here to learn more about the Chroma Studio](#)




PROFILES TAB

The Profiles tab is a convenient way of managing all your profiles and linking them to your games and applications.

Devices


View which Razer device is using a specific profile using the Devices subtab.



You can import Profiles from your computer or from the cloud through the import button () or create new profiles within the selected device using the add button (). To rename, duplicate, export, or delete a profile, simply press the Miscellaneous button (). Each profile can be set to automatically activate when you run an application using the Linked Games option.

Linked Games


The Linked Games subtab gives you the flexibility to add games, view devices that are linked to games, or search for added games. You can also sort games based on alphabetical order, last played, or most played. Added games will still be listed here even if it is not linked to a Razer device.



To link games to connected Razer devices, simply click on a game from the list, and then click **Select a device and its profile to launch automatically during gameplay** link to select the Razer device it will link with. Once linked, you may click on the Miscellaneous button (●●●) of the corresponding device to select a specific profile.

SETTINGS WINDOW

The Settings window, accessible by clicking the (⚙️) button on Razer Synapse, enables you to configure the startup behavior and display language of Razer Synapse, view the master guides of each connected Razer device, or perform factory reset on any connected Razer device.



General tab

The default tab of the Settings window. The General tab enables you to change the software's display language, start-up behavior, and display theme. You may also manually sync your profiles to the cloud (↻️) or view the master guide of all connected Razer devices and installed modules.

Reset tab

The Reset tab allows you to perform a factory reset on any connected Razer device and/or reset Razer Synapse tutorials to acquaint yourself again with Razer Synapse's new features on its next launch.



Note: Performing a factory reset on devices without on-board memory will only create a new profile for your device on Razer Synapse 3 using the default settings.

About tab

The About tab displays brief software information and copyright statement and provides relevant links for its terms of use. You may also use this tab to check for software updates, or as a quick access to Razer's social communities.

6. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Tomahawk Mini-ITX, we suggest that you adopt the following guidelines:

1. Place the chassis on a clean and stable surface that allows adequate air ventilation.
2. Don't use or place the chassis and any of its components near water, moisture, or other wet surfaces; or place the chassis near any heat, naked flame, or other hot surfaces such as radiators, stoves, fireplaces, and candles.
3. Use caution when operating the desktop PC to avoid electrical shock or damage, such as unplugging the power supply during thunderstorms, ensuring that your hands are dry before using (and handling) the desktop PC, keeping it away from any source of liquid and/or heat source, and using all other reasonable precautions needed under the circumstances.
4. When connecting external devices to your desktop PC, carefully plan how the wires will be placed. Protect any connected cables from being trod on or pinched, particularly at plugs, convenience receptacles, or the point where they exit from.
5. Take extra caution when removing and/or reattaching the glass panel. Once removed, place the glass panel on a stable surface first before taking any action on its internal components.
6. When unplugging any connected devices and/or cables, always pull the cable or device's plug or connector. Don't forcefully tug on its cord.
7. Don't place any heavy items on top of the chassis.
8. Make sure that the desktop PC is off, unplugged from the outlet, and that all connected devices are powered off and unplugged (if any) before installing or uninstalling any internal component to and/or from the chassis.

7. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2020 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this Master Guide. Furnishing of this Master Guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Tomahawk Mini-ITX (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.